© ATX Hardware GmbH West | Version 2018

Maintenance recommendation

ATX Hardware



To ensure that the functions are consistently maintained, the number of strokes must be determined by the adapter. The following maintenance measures must be carried out at regular intervals:

		Heavens			
	daily	10.000	20.000	50.000	100.000
Visual inspection of the adapter for damage	х				
Clean adapter from dirt and dust with recommended cleaner		Х			
Remove impurities at interfaces with recommended cleaner				Х	
check tight fit of screw connections of moving parts, tighten if necessary		х			
check tight fit of guide bolts, tighten if necessary		х			
check bushings for wear, replace if necessary					х
Clean bearings, running surfaces and guide rails, lubricate if necessary				х	
Check PCB supports for completeness and height (3mm), replace if necessary		х			
Check downholder for tight fit, completeness and dimensional accuracy, replace if necessary (risk of injury!)		х			
Check springs of pin carrier plate for breakage and function, replace if necessary			Х		
Check specimen for exact positioning in the holders (check catch pins or contour holder)			х		
Clean or replace contact needles depending on type with subsequent hit pattern check			х		
xCheck function of gas pressure damper and spring adjuster, replace if performance decreases	х	Х			
xCheck floating bearings for function			х		
Check stroke of contacting by means of measuring needle				Х	
with pneumatics installed:					
Check whether the operating pressure is set to bar.		Х			
check tightness of pneumatic cylinder screw connections		Х			
acoustic check for pressure loss of all components in quiet environment		Х			
for vacuum fixtures:					
Visual check: parallel downward movement of the carrier plate or vacuum hood, check springs if necessary.		х			
Acoustic check for loss of vacuum of all components in a quiet environment.		Х			

We recommend the following products for maintenance:	Order no.	
Hit spray	916003	
Antistatic plastic cleaner - also suitable for Plexi	912002	
Lifting gauge needle 75mil	699006	
Lifting gauge needle 100mil flat head	699021	
Lifting gauge needle 100mil round head	699005	